

ROCKY MOUNTAIN

H A R D W A R E

DOOR PREPARATORY SPECIFICATIONS

Passage Cremone Bolt - Interior

Notes:

1. Backset should be adjusted so escutcheon fits on door stile.
2. No prep needed on edge of door.

