



Olympus Grip

	<b>A</b>	<b>B</b>	<b>C</b>	<b>D</b>	<b>E</b>	<b>F</b>
<b>G650</b>	7 1/2"	8 1/2"	1"	1 5/8"	2 5/8"	1"
<b>G651</b>	10"	11 1/16"	1 1/16"	1 5/8"	2 11/16"	1 1/16"
<b>G652</b>	14"	15 1/8"	1 1/8"	2"	3 1/8"	1 1/8"
<b>G659</b>	15"	16 1/8"	1 1/8"	2"	3 1/8"	1 1/8"
<b>G689</b>	18"	19 1/16"	1 1/16"	1 5/8"	2 11/16"	1 1/16"
<b>G653</b>	22 7/8"	24"	1 1/8"	2 1/2"	3 5/8"	1 1/8"
<b>G657</b>	24"	25 1/8"	1 1/8"	2 1/2"	3 5/8"	1 1/8"
<b>G671</b>	42"	43 1/8"	1 1/8"	2"	3 1/8"	1 1/8"
<b>G663</b>	60"	61 3/8"	1 3/8"	2"	3 3/8"	1 3/8"
<b>G691</b>	84"	85 1/2"	1 1/2"	2"	3 1/2"	1 1/2"