



Olympus Grip

	A	B	C	D	E	F
G650	7 1/2"	8 1/2"	1"	1 5/8"	2 5/8"	1"
G651	10"	11 1/16"	1 1/16"	1 5/8"	2 11/16"	1 1/16"
G652	14"	15 1/8"	1 1/8"	2"	3 1/8"	1 1/8"
G659	15"	16 1/8"	1 1/8"	2"	3 1/8"	1 1/8"
G689	18"	19 1/16"	1 1/16"	1 5/8"	2 11/16"	1 1/16"
G653	22 7/8"	24"	1 1/8"	2 1/2"	3 5/8"	1 1/8"
G657	24"	25 1/8"	1 1/8"	2 1/2"	3 5/8"	1 1/8"
G671	42"	43 1/8"	1 1/8"	2"	3 1/8"	1 1/8"
G663	60"	61 3/8"	1 3/8"	2"	3 3/8"	1 3/8"
G691	84"	85 1/2"	1 1/2"	2"	3 1/2"	1 1/2"